

**University of Cape Coast**  
**Department of Computer Science and Information Technology**  
**Embedded systems Quiz 1**

Course Code: CSC321


Duration: 1hr 20mins

Date: 16<sup>th</sup> February 16, 2023

---

### **The DHT11 Temperature and Humidity Sensor**

The DHT11 is a digital temperature and humidity sensor featuring its own proprietary communication protocol. It uses a single GPIO line (GPIO 22) to serially transfer its temperature and humidity measurement.



MicroPython already has a driver for the DHT type sensors (DHT11 and DHT22) included in its binary making it very easy to read the temperature and humidity values. The driver however hides the protocol from the user and the user is unable to see what is going on behind the scene.

For this reason, a second driver allowing to read raw bit values as they appear in the DHT11 protocol has been added to the ESP32. This will help you understand how the DHT11 actually works and what the driver is doing to extract the temperature and humidity values.

This driver (module `dht11Raw`) starts a measurement on the DHT11 and then scans the DHT11's data line every 4 us keeping it state in a 32\*32bit array. The first measured bit is the highest significant bit of the first array element and the last measured bit is the lowest significant bit of the last element in the array.

The DHT11 data sheet has been attached to this document.

**Question:** Write a script **dht11.py** which extracts data from the DHT11 automatically and prints it every 30s.

A guide is provided below

## Getting the Raw Data

Get the raw data of the DHT11 and write it to a file on the ESP32. The *dht11Raw* module has a single function: `dht11ReadRaw (pin, dht11Data)`

The data must be an integer array with 32 integer values. You can create this with:

```
import array  
dht11Data = array.array("I",[0]*32)
```

This will create the needed array and fills it with zeros. Once you have the data, write the data in a suitable format to a file on the ESP32 with the path `"/data/dht11.txt"`.

Before writing to the file, check if the `"/data"` directory exists. Make use of **try/except** clause using the **system call** (uos) to validate the existence of `"/data"`.

Write the data in hex text format with 8 hex characters per integer number.

Example:

```
0x007e001f  
0x000ffff0  
0x00ffff00  
0x0ffff000  
0xfffe000f  
0xfe001fff  
0xfe001f80  
0x07c003f0  
0x00f8007e  
0x001f000f  
0x8007e001  
0xf8007c00  
0x3e000fff  
0xe001f800  
0x7fff0007  
0xfff000ff  
0xff000fc0  
0x03e001f8  
0x007c003f  
0x000fffe0  
0x01f8007c  
0x001f000f  
0xfff000f8  
0x007fff80  
0x07fff800  
0x7c003fff  
0xc003f000  
0xffffffff  
0xffffffff  
0xffffffff  
0xffffffff
```

Extract the individual bits from the raw data and write them to an "uncompressed file". Each data entry will contain either 0 or 1 (convert the hex values to Binary). Example below



Read the raw data and **Extract temperature** and **humidity** from this measurement and finally calculate the **checksum**.

